

RG-NBR2500

1.	NBR		2
1.1	NBR2500		2
2.			4
3.			8
3.1			8
3.2			8
3.3			8
4.			9
4.1	IP		9
4.2	PPPoE		13
4.3	DHCP IP		16
5.	Web		21
5.1	Web		21
5.2			22
6.	NBR		29
6.1	NBR		29
6.1.1	WAN		29
6.1.2	LAN		29
6.1.3			29
6.2			30
6.2.1			30
6.2.2			31

1. NBR

1.1 NBR2500




1-7 RG-NBR2500

NBR2500


	NBR2500			
WAN	2	10/100	RJ45	Auto MDI/MDIX
	1	10/100/1000M	RJ45	Auto MDI/MDIX
LAN	5	10/100/1000M	RJ45	Auto MDI/MDIX

1 1 0 0 1 238.49 341.81 Tm1.53 23.64 eW*nBT/2 10.566 T1 5 E1

	30W
	0 45
	-40 70
	10 90%RH




2-3



2-4

2-5 Console PC
PC COM1 NBR Console COM1



2-6 PC
Console

9600Bit/S

8

1

3.

3.1

-
-



A

3.2

3.3

-
-
-
-

	NBR80	NBR2000
“ Status ”	NBR2500/NBR3000	“ SYSTEM ”
NBR1100E/NBR1200/NBR1200G/NBR1100G		“ ”
	Console	

4.

WEB

Console

enable

enable

NBR>

NBR>enable

Password:

<=

NBR# setup

<=

setup

NBR

setupNBR **RGOS**

CD-ROM

RGOSwww.ruijie.com.cnNBR **setup**


```

1.
2.
3.
    (1 - 3)[3]:
        [yes]:
WAN    ping    [no]:
        IP      [no]:

        DNS     (DNS    )[no]:

        :
        :
        :admin
telnet      :remoteuser
        :
WAN 0:      IP
        : 218.5.19.2 255.255.255.0
        :218.5.19.1
NAT        :
        : 100 Mbps
        :
        : 192.168.0.1 255.255.255.0
        ARP: 1 Seconds
        :
        : LAN0          : LAN3
        :
        :
        :
WAN    ping    :
        DNS     (DNS    ):
        [yes]:

LAN    IP          telnet LAN    IP          !

!
.
NBR1#show running-config
Building configuration...
Current configuration : 1962 bytes

!
version 9.17 (building 9) for NBR
enable password 7 073f07221c1c
!
access-list 3198 deny tcp any any eq 135
access-list 3198 deny tcp any any eq 445
access-list 3198 permit ip any any
access-list 3199 deny icmp any any echo
access-list 3199 deny tcp any any eq 135
access-list 3199 deny tcp any any eq 445
access-list 3199 permit ip any any
access-list 99 permit any
dialer-list 1 protocol ip permit
mirror master lan 0 slave lan 3 all
!
!
!
service sequence-numbers

```

NBR

```
service timestamps debug datetime
service timestamps log datetime
no service password-encryption
!
interface FastEthernet 0/0
 ip nat inside
 ip access-group 3198 in
 no ip redirects
 no ip mask-reply
 no ip proxy-arp
 ip address 192.168.0.1 255.255.255.0
 arp gratuitous-send interval 1 5
!
interface FastEthernet 1/0
 ip nat outside
 ip access-group 3199 in
 no ip redirects
 no ip mask-reply
 no ip proxy-arp
 ip address 218.5.19.2 255.255.255.0
 duplex auto
 speed auto
!
interface FastEthernet 1/1
 duplex auto
 speed auto
 shutdown
!
interface Null 0
!
ip nat pool nbr_setup_build_pool prefix-length 24
 address 218.5.19.2 218.5.19.2 match interface FastEthernet 1/0
!
ip nat inside source list 99 pool nbr_setup_build_pool
ip nat translation max-entries 7000
ip nat translation per-user 0.0.0.0 1000
ip nat translation udp-timeout 150
ip nat translation icmp-timeout 30
ip nat translation tcp-timeout 600
ip nat translation finrst-timeout 20
ip nat translation dns-timeout 30
security anti-wan-attack level high
security anti-lan-attack
!
ip route 0.0.0.0 0.0.0.0 FastEthernet 1/0 218.5.19.1
!
line con 0
line vty 0
 login
 password 7 110022081d5e0834012e3e
line vty 1
 login
 password 7 072c06221a062210014f1f
line vty 2
 login
 password 7 093d101f2811175f1e2400
line vty 3
 login
 password 7 050a03330c3b1007340000
line vty 4
 login
 password 7 08112a181d330007590833
```

!
!
end

4.2 PPPoE

ADSL

Internet

```

:
1. IP
2. PPPoE
3. DHCP IP
   (1 - 3)[1]:
   PPPoE :
   PPPoE :pppoepassword
   ISP Mbps (1-100)[ 100]:

: telnet LAN IP
LAN
LAN IP[192.168.0.1]:
LAN [255.255.255.0]:
ARP[yes]:
      (1 - 3600)[1]:
1      (1 -100)[5]:
      [no]: NBR

      [yes]:
      [yes]:

:
1.
2.
3.
   (1 - 3)[3]:
   [yes]:
WAN ping [no]:
   IP [no]:

   DNS (DNS ) [no]:

:
:
:
telnet :
:
WAN 0:
:
:
: 100 Mbps
:
: 192.168.0.1 255.255.255.0
ARP: 1 Seconds
:
:
:
WAN ping :
DNS (DNS ):
[yes]:

```

```

!
NBR#show running-config

```



```


!
interface Null 0
!
!
ip nat pool nbr_setup_build_pool prefix-length 24
address interface dialer 0 match interface dialer 0
!
ip nat inside source list 99 pool nbr_setup_build_pool
ip nat translation max-entries 7000
ip nat translation per-user 0.0.0.0 1000
ip nat translation udp-timeout 150
ip nat translation icmp-timeout 30
ip nat translation tcp-timeout 600
ip nat translation finrst-timeout 20
ip nat translation dns-timeout 30
security anti-wan-attack level high
security anti-lan-attack
!
ip route 0.0.0.0 0.0.0.0 dialer 0
!
line con 0
line vty 0
login
password 7 04220b032c
line vty 1
login
password 7 1000012217
line vty 2
login
password 7 08163c1000
line vty 3
login
password 7 072b102a07
line vty 4
login
password 7 050d153b11
!
!
end

```

NBR WAN PC
 LAN

4.3 DHCP IP

WAN Internet
 192.168.0.1 DHCP
 Internet
 LAN IP LAN
 NAT



```
NBR >enable
```

```
!
```

```
NBR#setup
```

```
-----
ctrl-c      '['

:

[NBR]:

telnet
WAN (1- , 2 - , 3- , ) [1]:

internet WAN :
0. WAN 0
1. WAN 1
(0 - 1) [0]:

:
1. IP
2. PPPoE
3. DHCP IP
(1 - 3) [1]: 3
ISP Mbps (1-100) [ 100]:
ARP[no]:

: telnet LAN IP
LAN
LAN IP[192.168.0.1]:
LAN [255.255.255.0]:
ARP[yes]:
(1 - 3600) [1]:
```

1

(1 -100)[5]:

[no]:

NBR

[yes]:

[yes]:

:

14x1.0 4x1

```
access-list 99 permit any
dialer-list 1 protocol ip permit
!
service sequence-numbers
service timestamps debug datetime
service timestamps log datetime
no service password-encryption
!
interface FastEthernet 0/0
 ip nat inside
 ip access-group 3198 in
 no ip redirects
 no ip mask-reply
 no ip proxy-arp
 ip address 192.168.0.1 255.255.255.0
 arp gratuitous-send interval 1 5
!
interface FastEthernet 1/0
 ip nat outside
 ip access-group 3199 in
 no ip redirects
 no ip mask-reply
 no ip proxy-arp
 ip address dhcp
 duplex auto
 speed auto
!
interface FastEthernet 1/1
 duplex auto
 speed auto
 shutdown
!
interface Null 0
!
!
ip nat pool nbr_setup_build_pool prefix-length 24
 address interface FastEthernet 1/0 match interface FastEthernet 1/0
!
```

```
security anti-wan-attack level high
security anti-lan-attack
!
!
line con 0
line vty 0
  login
  password 7 131717470235173e3f0057
line vty 1
  login
  password 7 04251d0b31172a00012217
line vty 2
  login
  password 7 0132464e380c032b102a07
line vty 3
  login
  password 7 08112a181d330007590833
line vty 4
  login
  password 7 03513215092a063a061735
!
!
end
```

5. Web

Web


CD-ROM

5.1 Web

LAN

WAN

IP




5-2 “ (Y) ”

“ WEB ” “ ”

WEB

admin



5-3


web flash web htm js

“ ” “ WED ”

Web


5.2

NBR
NBR



5-4

“ ” LAN



5-5 LAN

LAN IP “ ” WAN IP Web

LAN IP LAN IP

快速配置

第一个外网口 (WAN0) 配置

请填写电信或网通等运营商提供的信息

线路类型

线路带宽 Mbps (有效值1-1000) *

线路运营商 ☐ 电信 ☐ 网通

其他 *

上一步 下一步

5-7 WAN0 IP

“PPPoE”

快速配置

第一个外网口 (WAN0) 配置

请填写电信或网通等运营商提供的信息

线路类型

用户名

密码

线路带宽 Mbps (有效值1-1000) *

5-8


ADSL

1-1000M

WAN0


“ ”

WAN0



5-9 WAN0 PPPoE

WAN0				WAN1	“	(wan1)”
	“	”	“	”		
	LAN	IP				IP Web
			WAN	WAN1		WAN WAN




5-10 WAN


WAN

“ ”

WAN



5-11



5-12

LAN IP

IP

Web

6. NBR

NBR

NBR

NBR

3

4

GB50174-93

4

4

5

6.2

6.2.1

IN OUT

1 WAN



6-1 WAN

- i. ADSL Modem NBR ADSL Modem
IN NBR WAN OUT
- ii.
- iii.
- iv. ADSL Modem NBR

2 LAN



6-2 LAN

- i. NBR
- ii. IN NBR LAN NBR OUT
- iii.
- iv.
- v. NBR NBR

6.2.2

RJ45