

copyright © 2017



1		1	
2		1	
3		1	
4		2	
5		1	
6		1	
7		1	
8		2	
9		1	

		RG-IIB-K75A	RG-IIB-K86A
		1741.7x103.4x1060.2	1995.2x111.9x1206.3
		mm Ĩ 400mm	mm Ĩ 400mm
	(OPS)		

5000m

5000m

5000m


3


4

44

11

		/PCS	
		1	
		2	
	VESA PE 0.04mm*150mm*190mm	1	
	8*80m	8	
	4*10mm 8mm	2	+
	M5*100mm	2	+






1

2 M4

A


160KG



2 M5*100

2mm-10mm

B;



3

10mm


8*80

4

8


85mm

C



4


D



5

M5*100

E



gk

USB

MstarUpgrade_848.bin

U

“ ”



U USB

USB2.0

10S

È

2

“ ”



“ Rr

1


2
USB TOUCH

HDMI

现象	解决方案
没有图像 没有声音	- 检查是否插上电源线。 - 按本机或遥控器上的POWER键检查是否为待机状态。
声音正常但色彩不佳	- 选择合适的图像模式。 - 调节图像的亮度。 - 调节图像的色彩饱和度。
无声音	本机是否处于静音状态。按静音键取消静音。

IDV

Windows 10



1

2

①

USB

USB

②

“ ”

OSD

>

3

4

2-3
