

RG-IIB-N86A

copyright © 2017





()

	OPS		

--	--	--	--

()

(Display)	LCD (Size)	86"
	LCD	A
	(Backlight type)	LED
	(Resolution)	3840*2160 (pixels)
	(Brightness) (typ)/(min)	350cd/m ² (min.)
	(Brightness) (typ)/(min)	400cd/m ² (typ.)
	(Contrast Ratio) (typ)/(min)	1200:1 (typ.)
	(Response Time) (typ)/(min)	8ms (typ.)
	(Pixel Pitch)	0.4935mmx0.4935mm
	(Refreshing frequency)	60Hz
	(Viewing angle)	178°(H)/178°(V)
	(Life Time) (typ)/(min)	30,000 hrs (min.)
	(Color Gamut)(X% NTSC)	65%
	(View area)	1897mmx1068mm
	(Display Colors)	1.07B(10bit)
		16:9
		10000K
		2G
		16G/EMMC
		9.0
		Intel I5-8400
		8G
		256 SSD
		WINDOW 10



	10% ~ 90% RH Non-Condensing
	0 5000
MTBF	3
	45db

()


1

2

3

4

5



()

1

2

3



安装工具

1.卷尺

2 电锤

4.自攻螺钉M12*130和M16*160


5.电钻

6.电钻


7.铅笔

()



5 -			
1 -			
3 -			
2 -			
4 -			



()



86	4024mm*1224mm*90mm	2000mm*1224mm*90mm 1012mm*1224mm*90mm	60KG 35KG




3 M6 5 M8*150 1 M8*80
+M4*30



5

ok





()

()

()

Trouble shooting

1

1

2

现象	解决方案
没有图像 没有声音	- 检查是否插上电源线。 - 按本机或遥控器上的POWER键检查是否处于待机状态。
声音正常但色彩不佳	- 选择合适的图像模式。 - 调节图像的亮度。
色彩不佳	调节图像的色彩饱和度。
图像正常，没有声音	本机是否处于静音状态，按静音键取消静音。

3

Windows 10

